

# Duo-G2D

For operation manuals and other technical documents please see links below.

To update your receiver now (and frequently later) please visit our website and download the latest firmware.

Here are links to the Duo-G2D firmware, documentation, and utilities:

- Duo-G2D OEM Board Newest Firmware Version

<http://www.javad.com/jgnss/support/update.html>

- Firmware Loader (Firmware Loading Software) free

<http://www.javad.com/jgnss/products/software/firmwareloader.html>

- Duo-G2D OEM Board Datasheet

[http://www.javad.com/downloads/javadgnss/sheets/Duo-G2D\\_Data\\_Sheet.pdf](http://www.javad.com/downloads/javadgnss/sheets/Duo-G2D_Data_Sheet.pdf)

- Duo-G2D OEM Board Physical Specifications


[http://www.javad.com/downloads/javadgnss/sheets/Duo-G2D\\_DRW.pdf](http://www.javad.com/downloads/javadgnss/sheets/Duo-G2D_DRW.pdf)

- TriVU (Windows GUI Configuration Utility) free

<http://www.javad.com/jgnss/products/software/trivu.html>

- GREIS (GNSS Receiver External Interface Specification)

[http://www.javad.com/downloads/javadgnss/manuals/GREIS/GREIS\\_Reference\\_Guide.pdf](http://www.javad.com/downloads/javadgnss/manuals/GREIS/GREIS_Reference_Guide.pdf)



## Option Authorization File

JAVAD GNSS issues an Option Authorization File (OAF) to enable the specific options that customer's purchase.

An OAF allows customers to customize and configure the Duo-G2D OEM Board according to particular needs, thus only purchasing those options needed.

Typically, all Duo-G2D OEM Board receivers ship with a temporary OAF that allows the receiver to be used for a predetermined period of time (typically 60 days). When the receiver is purchased, a new OAF activates purchased options permanently. Receiver options remain intact when clearing the NVRAM or resetting the receiver.

For a complete list of available options and details, consult your dealer, or visit the JAVAD GNSS website

<http://www.javad.com/jgnss/products/options/index.html>

To load new OAF to receiver use the TriVU software (see link above).




1731 Technology Drive, San Jose, CA 95110 USA  
Phone: +1(408)573-8100 Fax: +1(408)573-9100

[www.javad.com](http://www.javad.com)

Copyright © JAVAD GNSS, Inc., 2009

# Duo-G2D

## Support Inquiries



Ask us questions and view our answers from over 20 highly qualified specialists (including Javad himself). It is much better than e-mails, or phone calls.


In order to address customer support inquiries in a timely and effective manner; JAVAD GNSS has created a powerful online question utility. To take advantage of this utility, please log into your JAVAD GNSS account and select **QUESTIONS** from the drop down menu.

The questions utility may also be reached by following this link,

<http://www.javad.com/cgi-bin/jgnss/cgi?Action=DrawQuestionManager&initFormCurrentSavez=on>

When the JAVAD GNSS support team posts a response to your inquiry, an email containing this response is sent to the email address you have registered in your profile.

Description	I/O	Signal Name	Pin #	Pin #	Signal Name	I/O	Description
Power Ground		PGND	<b>A1</b>	<b>B1</b>	PGND		Power Ground
+4.5 to +40 VDC Power Input	I	PWR_IN	<b>A2</b>	<b>B2</b>	PWR_IN	I	+4.5 to +40 VDC Power Input
Factory use only, must be left open		FUO	<b>A3</b>	<b>B3</b>	COMMSW#	I	Active Low Command Input (FN Button) *1
Reserved		-	<b>A4</b>	<b>B4</b>	KA_PWR	I	Keep-Alive Power input for Real-Time Clock (+4.5 to +40 VDC, 10µA typ)
External LED Control *2	O	LED2_RED	<b>A5</b>	<b>B5</b>	LED1_RED	O	External LED Control *2
External LED Control *2	O	LED2_GRN	<b>A6</b>	<b>B6</b>	LED1_GRN	O	External LED Control *2
Signal Ground		GND	<b>A7</b>	<b>B7</b>	USB_PWR	I	USB port Power Input line
USB port D- line	I/O	USB_D-	<b>A8</b>	<b>B8</b>	USB_D+	I/O	USB port D+ line
Serial port A TXD line	O	TXDA	<b>A9</b>	<b>B9</b>	CTSA	I	Serial port A CTS line
Serial port A RXD line	I	RXDA	<b>A10</b>	<b>B10</b>	RTSA	O	Serial port A RTS line
Serial port C TXD line	O	TXDC	<b>A11</b>	<b>B11</b>	CTSC	I	Serial port C CTS line
Serial port C RXD line	I	RXDC	<b>A12</b>	<b>B12</b>	RTSC	O	Serial port C RTS line
RS-422 port TXD+ line	O	TXDD+	<b>A13</b>	<b>B13</b>	TXDD-	O	RS-422 port TXD- line
RS-422 port RXD+ line	I	RXDD+	<b>A14</b>	<b>B14</b>	RXDD-	I	RS-422 port RXD- line
Signal Ground		GND	<b>A15</b>	<b>B15</b>	-		Reserved
Reserved		-	<b>A16</b>	<b>B16</b>	-		Reserved
Serial port B TXD line	O	TXDB	<b>A17</b>	<b>B17</b>	CTSB	I	Serial port B CTS line
Serial port B RXD line	I	RXDB	<b>A18</b>	<b>B18</b>	RTSB	O	Serial port B RTS line
CAN1 port CAN-H line	I/O	CAN1H	<b>A19</b>	<b>B19</b>	CAN1L	I/O	CAN1 port CAN-L line
CAN2 port CAN-H line	I/O	CAN2H	<b>A20</b>	<b>B20</b>	CAN2L	I/O	CAN2 port CAN-L line
Factory use only, must be left open		FUO	<b>A21</b>	<b>B21</b>	-		Reserved
Signal Ground		GND	<b>A22</b>	<b>B22</b>	1PPSA	O	1 Pulse Per Second output A *3
Signal Ground		GND	<b>A23</b>	<b>B23</b>	1PPSB	O	1 Pulse Per Second output B *3
Signal Ground		GND	<b>A24</b>	<b>B24</b>	EVENTA	I	Event input A *4
Signal Ground		GND	<b>A25</b>	<b>B25</b>	EVENTB	I	Event input B *4
Configurable Logic-Level I/O 0 line	I/O	GPIO0	<b>A26</b>	<b>B26</b>	GPIO1	I/O	Configurable Logic-Level I/O 1 line
Configurable Logic-Level I/O 2 line	I/O	GPIO2	<b>A27</b>	<b>B27</b>	GPIO3	I/O	Configurable Logic-Level I/O 3 line
Signal Ground		GND	<b>A28</b>	<b>B28</b>	RESET_IN#	I	Active Low Reset input *5
Ethernet port TX+ line	O	LAN_TX+	<b>A29</b>	<b>B29</b>	LAN_TX-	O	Ethernet port TX- line
Signal Ground		GND	<b>A30</b>	<b>B30</b>	LAN_LED	O	Ethernet port control for external LED
Ethernet port RX+ line	I	LAN_RX+	<b>A31</b>	<b>B31</b>	LAN_RX-	I	Ethernet port RX- line
Active Low input for ON/OFF switch *7	I	ONOFFSW#	<b>A32</b>	<b>B32</b>	IRIG_OUT	O	IRIG port output line *6



\*1. Active Low input from the FN button of the MinPad. Must be left open if not used.

\*2. LED1\_GRN and LED1\_RED are used to control the STAT LED of the MinPad.

\*3. Voh>1.8V at 50 Ohm load.  
\*4. Internal pull-up 5 kOhm to +3.3V  
\*5. Connect to ground to activate. Internal pull-up 2 kOhm to +3.3V.  
\*6. AM sine-wave signal; 2.1Vp-p (Mark), 0.7Vp-p (Space).  
\*7. Active Low input which is equivalent to ON/OFF button of the MinPad. The pin must be connected to GND permanently if the board is required to turn on automatically any time external power is applied to pins A2 and B2.

\*4. Internal pull-up 5 kOhm to +3.3V  
\*5. Connect to ground to activate. Internal pull-up 2 kOhm to +3.3V.

\*6. AM sine-wave signal; 2.1Vp-p (Mark), 0.7Vp-p (Space).

\*7. Active Low input which is equivalent to ON/OFF button of the MinPad. The pin must be connected to GND permanently if the board is required to turn on automatically any time external power is applied to pins A2 and B2.

## Read this First